Basic instructions for tester use



You will get:

- USB Tester
- 2.USB alligator clip
- 3.Micro-USB adapter(OTG adapter)

Tester Button Description Press Once-Click: Switch the Display Interface

Fast Double-Click: Capacity mAH Clear Fast Press Three-Click: Current WH Clear Fast Press Four-Click: Time Clea Fast Press Five-Click: Switch Data Storage Group Long Press Button, Clear the current group data

input port of the tester to enable the USB C charging function.

How to test USB C devices


Insert a Micro-usb adapter(OTG Adapter) into the Micro-usb

If the OTG Adapter is not inserted, the tester may not display the screen.

Scope of application: Micro-usb cable, USB A to USB C Cable,

USB C to USB C Cable. USB A Charger, USB C Charger, Power Bank

and other USB devices. **Common Problem** 1. How to use the tester on USB C charger/Cable?



The tester beeps and shuts down. Answer: The tester supports a voltage and current range of 3.6V~32V, 0~5.1A The working temperature

Answer: Insert a Micro usb adapter (OTG Adapter) into the Micro usb input port.

is - 10 °~60°. Beyond this range, the tester will automatically shut down. Early warning range of initial

voltage and current of tester:>10A,>35V<0A If it is manually adjusted to>2A,>5V, most chargers will beep and turn off when using this adjusted tester. 3. The data before and after the tester is pulled out are different.

Answer: The tester retains the data of 2-3 seconds before unplugging. the

information is correct and there is no error.

4. How to check the charger. The cable supports fast charging. Answer: If you switch to the 4-wire data interface and display "FCP"and "FAST", fast charging is supported. How to check the quality of the charger.

Answer: Record the voltage and current supported by the charger, insert the tester to connect the cable to the mobile phone/load, and the tester displays

excellent; if the voltage is lower than 5V, the quality is poor. 6. Check the power bank power. Answer: The power bank is fully charged, insert the tester into the mobile phone or load, and discharge quickly. mAh capacity * 90%=power bank capacity.

the voltage and current. If 5V/3A is supported, the quality of the charger is


to Load, quickly discharged, and acquired data.

Check the phone power.

=Phone mAh capacity. (which is close to the phone battery capacity) **Tester Phone Capacity**

The phone is fully charged, plugged into the tester, cleared Wh data, connected

Electricity: Wh/3.75V(Phone battery voltage)=Capacity value X 1000 X90%




Basic use method of tester



Test Socket

Test the charger/cable



usb c to usb c Cable.

V+:5.13V


Tme:0000:00:00

not support fast charging, "FCP" "FAST" will not be displayed.

FCP

D+:0.30V FAST | 0000.00Wh

USB A to USB C Cable supported by the socket. The Socket has fast charging speed and excellent quality. Test Charger/Cable



Output voltage of corresponding

Qualcomm QC2.0 B protocol high voltage

iPad 2.4A current charging mode

20V charging

high current output

Samsung phone fast charge recognizes

high current output

protocol

Whether to support Fast charging Support USB A/USB C Charger, usb a to usb c Cable, Micro-usb Cable

Test charging cable

V-

0V

ov

0V

0V

Protocol Type

iPhone Fast

(BC 1.2 protocol) Samsung phone fast charge mode

Fast Charging shows "FCP" "FAST Tester Charger Whether to support Fast charging **Test Charger**

Insert the tester into the charger, connect Load, adjust the current to 3A, if it supports fast charging, the fifth interface will display "FCP" "FAST". If it does

Use a charger that has been tested by the tester to support fast charging, plug

cable. If the fifth interface displays "FCP" and "FAST", it supports fast charging.

Partial charging protocol voltage logic table

D-

0V

3.3V

2.4V

V+

5V (Default)

20V

4.8~5.2V

4.8 ~ 5.2V

the corresponding cable into the charger, and adjust to 3A after connecting the

CPU:18°C/08325mAh

0.00A/0000.00W

Qualcomm QC2.0 default 5V output Qualcomm 2.0 Qualcomm QC2.0 default 9V charging 0V 3.3V 0.6V 9V fast charge ov 0.6V 0.6V 12V Qualcomm QC2.0 default 12V charging protocol

If it does not support fast charging, "FCP" "FAST" is not displayed.

Corresponding voltage value of 4 lines of fast charger

protocol for various USB chargers

D+

0.6V

3.3V

2.4V

1.2V

0V 2.7V 2V iPhone 2.1A current charging mode 4.8 ~ 5.2V Charge iPhone 1A current charging mode 0V 2V 4.8 ~ 5.2V 2.68V Agreement iPhone 0.5A current charging mode ov 2V 2V 4.8 ~ 5.2V Android DCP Android phone fast charge recognizes **0V** identification 4.8 ~ 5.2V Short circuit D+D-

1.2V

The above information is provided by various mobile phone manufacturers. For more agreement information, please check on Google.

How to use the tester with high difficulty

Troubleshooting

1. Connection sequence: charger+USB C cable+tester. At this time, the tester screen does not display.

answer:1. No micro usb adapter is inserted, but the connection sequence is: USB C charger+tester USB

Answer: 1. The micro usb input port is inserted with a micro usb adapter, and the USB C cable is connected to the Tester Type-c output port. At this time, the screen will not display. It needs to connect the mobile phone or load to form a circuit to display. It is not the tester that is damaged. 2. The tester is not plugged in the Micro USB adapter. However, sometimes the screen is displayed,

After connecting the tester to the mobile phone, switch the tester display interface to the fifth, and judge the relevant protocols supported by the charger according to D+/D -, V+/V -. It can be used to judge the fast charging mode of the charger. if If you need more charging protocol voltage logic tables, please contact us at E-mail: nuw.17671@mail.ru

C input to USB C output+USB C to USB C Cable+Phone. At this time, the charging protocol starts naturally, and the tester displays. 2. No micro usb adapter is inserted, but the connection sequence is: USB C charger+tester USB C input to USB A output+USB A to USB C Cable+Phone. At this time, the charging protocol does not start, and

4. The Micro USB adapter is missing.

Amazon. Please also check the manual or product page.

the tester does not display.

sometimes it is not.

device.

3. The tester USB C input is inserted into the charger, USB A output is inserted into the load, and the current is adjusted. The screen does not display.

Answer: The micro usb input port of the tester is not inserted into the micro usb adapter, and the protocol is not started, so it is not displayed. However, if the micro usb input port of the tester is not plugged into the micro usb adapter, and the tester USB A input port to the charger to USB A output to Load, the tester will display, because there is no charging protocol related to USB C, the tester will display.

Answer: If the Micro usb adapter (OTG adapter) is lost, the tester cannot test the USB C device. Use the Micro usb charger (not OTG adapter), insert the Micro usb input port, and then you can test the USB C

5. The tester beeps and shuts down. Answer: The tester supports a voltage and current range of 3.6V~32V, 0~5.1A The working temperature is - 10 °~60°. Beyond this range, the tester will automatically shut down. Early warning range of initial

beep and turn off when using this adjusted tester. Prompt again:

why the tester cannot work for USB C.

If you find that the tester cannot work for USB C, it is likely that you have not inserted a Micro usb adapter (OTG adapter) into the Micro usb input port or not fully inserted it, which is the main reason

If you have any doubts or need help, please contact us at E-mail:nuw.17671@mail.ru. Or email us via

voltage and current of tester:>10A,>35V<0A If it is manually adjusted to>2A,>5V, most chargers will